

Installation Instructions

1. The Honda Civic with original navigation has CAN wires in a different connector to those cars without navigation.
2. Cut the pink and Pink/Black wires off the 20 way grey connector on the PAC RP4-HD11 harness. Leave the Red, white and white black in place.
3. Identify the 24 pin grey connector shown below in the car. Join the Pink to the Pinkish Brown cable shown below (pin 19), and the Pink/Black to the Blue/Silver (pin7).
4. For phone answer and reject functions connect the White/green wire under the steering column to pin 3 of the 16 way connector (as per the PAC instructions).

