

## User Manual Inbay Charger Cup / Inbay pockets

The Inbay wireless charging system enables you to charge any Qi-compatible smartphone without any annoying cables  
Smartphones which do not support the Qi-standard can be upgraded using a charging cover or Qi-receiver.

A list of available charging covers can be found at [www.inbay.systems](http://www.inbay.systems)

To charge the smartphone insert it into the Inbay pocket / charging cup - directly over the rubber mat

### Only for INBAY applications with LED

In idle mode of the Inbay pocket or charging cup the status LED lights red. When charging starts the status LED turns from red to blue and you hear once an acoustic signal.

When charging is completed the smartphone continuous to be supplied with power

In case of any trouble with your Inbay-System please take a look at the troubleshooting chart below:

Description	Explanation
LED is not illuminated	Ignition switched on? Please check connectors
LED is illuminated red	No Qi-compatible receiver found, or smartphone is not correctly positioned
LED blinks alternately red and blue	Smartphone is not positioned directly over the spool and has to be re-positioned
Error „this accessory may not be supported“ appears	This just shows a completed charging process Now the smartphone continuous to be supplied with power
The radio reception changes extremly - and/or rhythmic background noises can be heard	The reason for background noises is a malfunction of the antenna socket or the antenna cable. A replacement of the components will solve the problem